

## INSTRUCTION SHEET



### REAR ACCESSORY ELECTRICAL HARNESS

FOR 2017+ CAN-AM MAVERICK X3 & X3 MAX

**INCLUDED IN BOX:**  
(1) Power Harness  
(1) Instruction Sheet

**WARNING!**  
Do not overload the vehicle's  
electrical system!

**QUESTIONS?**



**EMAIL:**  
info@getklocked.com  
**CALL:** (605) 996.3700



1. Simply detach stock waterproof connector from rear firewall and unplug by lifting on clip.
2. Plug the female end of the harness back onto the male end of the OEM connector until clip locks.
3. Plug the male end of the harness into the female end of the OEM connector until clip locks.
4. Reattach retainer clips to firewall.
5. The pigtail leads wires get run to your LED whip light, lighted license plate, or third brake light.

**BLACK WIRE = GROUND LEAD**  
**RED WIRE = RUNNING LIGHT / ACC 12V+ LEAD**  
**ORANGE WIRE = BRAKE LIGHT 12V+ LEAD**

A harness can be plugged in on each side of vehicle. This is recommended for low current lights or to trigger a relay for larger high power lights. If circuit is overloaded it could cause the fuse to blow or damage the OEM wiring.

**Warning!** Do not overload the vehicle's electrical system!