

Billet Backplate - Can-Am® Maverick X3 Instructions

 hmfracing.com/equipment/can-am-maverick-x3/billet-backplate-can-am-maverick-x3/installation

Installation

1. Ensure that the machine is on level ground with wheels chalked.
2. Lift machines up with jack to remove tension on radius rods.
3. Loosen the (6) stock bolts from the original backplate and remove.
4. Install Billet backplate using the (6) stock bolts and torque to factory specifications.



Discussion
