

Defender HD Front Bumper, Can-Am® Commander Instructions

 hmfracing.com/equipment/can-am-commander/defender-hd-front-bumper-can-am-

Installation

1. Disconnect the **negative battery cable** from the **battery**.
2. Remove the original front bumper (and winch if so equipped)
3. Install the **IQ front bumper** using the supplied hardware.
4. Mount the **winch** to the **winch mounting plate**.









5. Connect the power, ground, and winch control wires.
6. Install the **IQ skid plate** using the supplied hardware. If you are installing a winch fairlead, it will be installed at the same time as the skid plate.
7. Connect the **negative battery cable** to the **negative battery post**.

Discussion

Hardware

-  (4) Bolt - Buttonhead - M8-1.25 X 20

-  (2) Bolt - Hex - M8-1.25 X 20
-  (2) Bolt - Hex - M8-1.25 X 55
-  (6) Nut - Nylock - M8-1.25
-  (1) Skid Plate, Can-Am® Commander
-  (12) Washer - Flat - 1/4"
-  (2) Washer - Flat - 3/8"

* Click thumbnails to enlarge

© Copyright 2020, HMF Engineering • 5111 West 164th Street • Brookpark, Ohio 44142

[terms](#) [privacy](#) 