RH-5R 5-Watt Radio
USER GUIDE
P.N. RH5R-V2*

Changing Channels

• Use **[⋀/⋁]** to scroll through the channels until you have reached your desired channel.

Dual Display

Out of the box, the RH-5R displays a single channel but has the capability to display two channels. This is useful if you continuously switch between channels or need to monitor 2 channels at once.

• To turn on the second channel display press **[F]**, **[0]**, **[6]**, **[F]**. Then press **[⋁]** to turn on. Press **[F]** to save and **[EXIT]** to leave the menu.
• To alternate between the top and bottom channels, press **[A/B]**.

Keypad Lock/Unlock

• To manually lock the keypad press and hold **[LOCK]** on the bottom left of the face of the radio until the "Lock" 🔒 symbol appears. To Unlock press and hold **[LOCK]** until the "Lock" 🔓 symbol disappears.

• To turn on Auto Lock press **[F]**, **[1]**, **[4]**, **[F]** followed by either **[/]** and **[EXIT]** to leave the menu. This feature locks the radio keypad if there is no key operation for 5 seconds.

FM Radio

• To activate FM Radio listening, press **[FM RADIO]**
• Use **[⋀/⋁]** or keypad to tune the desired frequency.

Monitor a Channel

• Hold **[MONI]** to temporarily change the squelch to zero allowing you to hear very weak signals.

Programming

• Please contact **RT Systems** for custom programming software and cables.

RT Systems
Phone: 800-921-4834
Web: https://www.rtsystemsinc.com/

Signal Strength   Keypad Lock   Battery Life

Dual Display Shown
Frequency A: Top displayed channel
Frequency B: Bottom displayed channel.

On/Off/Volume Knob

[CALL]
LED Display
Menu
Push-To-Talk
Accessory Port
[MONI]
[A/B]
Up/Down Select **[⋀/⋁]**
[FM RADIO]
[LOCK]
[EXIT]

Rugged Radios | www.ruggedradios.com | 888-541-7223

*This guide pertains to RH-5R radios without the flashlight between the antenna and volume knob. For radios with the flashlight, please refer to the Quick Start Guide for P.N. RH5R-U/V. If your radio does not match these instructions then you need a firmware update. Please call our tech department at 888-541-7223.